




# SparkFun RFID USB Reader

SEN-09963 RoHS



**Description:** The SparkFun RFID USB Reader is a simple to use, USB to serial base unit for the ID-3LA, ID-12LA, and ID-20LA readers. Simply plug a reader into the headers and attach a miniUSB cable. Open a terminal program of your choice at 9600bps 8N1, then scan your 125kHz ID tag and the unique 32-bit ID will be shown on the screen. The unit is based on a FTDI chip and comes with a read LED and buzzer.

This new revision uses SMD headers for the RFID module, and has a solder jumper which allows you to disable or enable the buzzer.

**Note:** This product does not come with the RFID reader. Check below for compatible readers.